


1. AUDIO SETTINGS

HD Radio™ SYSTEM SETTINGS

HD Radio™ system can be set using the procedure outlined below.


1 Press the “SETUP” button.




2 Touch “Audio”.




3 Touch “HD Radio Settings”.



4 Touch “HD Radio/Analog Setting”.



5 Touch the item to be set.



Screen button	Function
“All”	Touch to receive both analog and digital broadcasts.
“HD Only”	Touch to receive only digital broadcasts.
“Analog”	Touch to receive only analog broadcasts.

6 Touch “Save”.

iPod SETTINGS

When the track currently being played has cover art data, it can be displayed.


- 1 Press the "SETUP" button.



- 2 Touch "Audio".



- 3 Touch "iPod Settings".



- 4 Touch "Display Cover Art".



- 5 Touch "On" or "Off".
- 6 After iPod setting has been changed, touch "OK".

